




Attention: Any repairs or replacements must be done by a qualified person or an authorized service center.

Local DC: 1-800-676-7777
Factory Warranty: 1-800-207-9259
Fax: 1-800-207-9614
www.grip-rite.com

GRTS1200

with selectable trigger



GRTS1200

with selectable trigger

PARTS LIST

Item#	Part #	Description	Q'ty
1	GRTN5910	Hex. Soc. Hd. Bolt	1
2	GRTN3220	Bushing	1
3	GRTN3230	Deflector	1
4	GRTN6080	Hex. Soc. Hd. Bolt	4
5	GRTN5640	Cap	1
6	GRTN5180	Metal Shim	1
7	GRTN5170	Piston Stopper	1
8	GRTN5150	Spring	1
9	GRTN3350	O-Ring	1
10	GRTN2300	O-Ring	1
11	GRTN5120	Piston, Head Valve	1
12	GRTN5650	Cap, Gasket	1
13	GRTN5130	Seal	1
14	GRTN5950	O-Ring	1
15	GRTN5670	Cylinder Spacer	1
16	GRTN2140	O-Ring	1
17	GRTN5960	O-Ring	1
18	GRTN5660	Cylinder	1
19	GRTN5940	O-Ring	1
20	GRTN5140	O-Ring	1
21A	GRTN5680	Driver Assembly	1set
22	GRTN5690	Bumper	1
23	GRTN5700	Driver Guide	1
24A	GRTN5710	Body Assembly	1set
25	GRTN4430	O-Ring	1
26	GRTN4450	End Cap	1
27	GRTN2220	O-Ring	1
28	GRTN2240	O-Ring	1
29	GRTN800	Valve	1
30	GRTN2100	O-Ring	1

Item#	Part #	Description	Q'ty
31	GRTN6250	O-Ring	1
32	GRTN2170	O-Ring	1
33	GRTN805	Valve Plunger	1
34	GRTN830	Spring	1
35	GRTN2230	O-Ring	2
36	GRTN8100	Plunger	1
37	GRTN820	Plunger Cap	1
38A	GRTN8090	Trigger Assembly-Select	1set
39	GRTN2540	Spring Pin	2
40	GRTN790	Trigger Pin	2
41	GRTN2210	Grommet	2
42	GRTN5870	Guide, Contact Trip	1
43	GRTN5780	Upper Safety Lever	1
44A	GRTN5820	Adjusting Nut Assembly	1set
45	GRTN5810	Lower Safety	1
46	GRTN5030	E-Ring	1
47	GRTN5790	Spring, Safety	1
48	GRTN5770	Bushing	1
49	GRTN5800	Safety Cover	1
50	GRTN6070	Hex. Soc. Hd. Bolt	1
51	GRTN5740	Nose	1
52	GRTN5890	Hex. Soc. Hd. Bolt	2
53	GRTN5720	Driver Guide Cover	1
54	GRTN7270	Roll Pin	1
55	GRTN5730	Door	1
56	GRTN7280	Latch Door Pin	1
57A	GRTN5750	Latch Door Assembly	1set
58	GRTN5760	Latch Door, Cover	1
59	GRTN3990	Hex. Soc. Hd. Bolt	2
60	GRTN5860	Magazine Cap	1

Item#	Part #	Description	Q'ty
61A	GRTN7910	Magazine Assy	1
62	GRTN6060	Hex. Soc. Hd. Bolt	2
63	GRTN5840	Pusher	1
64	GRTN3950	Latch	1
65	GRTN4070	Spring	1
66	GRTN3960	Spiral Spring	1
67	GRTN3970	Roller	1
68	GRTN3980	Roller Pin	2
69	GRTN5850	Bracket	1
70	GRTN4060	Spring	1
71	GRTN6040	Flat Washer	1
72	GRTN5900	Hex. Soc. Hd. Bolt	1
73	GRTN3340	Locknut	1
74	GRTN2470	O-Ring	2
75A	GRTN4150	Belt Hook Assembly	1set
75A-1	GRTN4480	End Cap	1
75A-2	GRTN4110	Belt Hook	1
75A-3	GRTN4140	O-Ring	1
75A-4	GRTN4120	Cover Belt Hook	1
75A-5	GRTN4440	C-Ring	1

Special Kits

Item#	Part #	Description	Q'ty
	GRDAK1700	Driver Assembly Kit	1set
	GRRBK1700	Rebuild Kit	1set
	CASES1200	Tool Case	1
	MANS1200	Operators Manual	1
	GRTRK800	Trigger Valve Assembly	1set

IF SWITCHING FROM SINGLE USE TRIGGER TO SELECTABLE TRIGGER THE FOLLOWING PARTS MUST BE CHANGED AT THE SAME TIME

REF #'s 29, 31, 33, 36, and 38A