




Attention: Any repairs or replacements must be done by a qualified person or an authorized service center.

Local DC: 1-800-676-7777
Factory Warranty: 1-800-207-9259
Fax: 1-800-207-9614
www.grip-rite.com

GRC58A



GRC58A

PARTS LIST

REF #	PART #	DESCRIPTION	QTY
101	GRBN312	DEFLECTOR	1
102	GRBN308	BOLT ASSY	5
103	GRBN313	CAP	1
104	GRBN296	SEAL	1
105	GRBN314	COMPRESSION SPRING	1
106	GRBN297	O - RING	5
107	GRBN306	O - RING	1
108	GRBN315	HD.VALVE PISTON	1
109	GRBN316	O - RING	1
110	GRBN317	CYLINDER CAP SEAL	1
111	GRBN318	COLLAR	1
112	GRBN161	O - RING	1
113	GRBN319	DRIVER UNIT	1
114	GRBN320	O - RING	1
115	GRBN321	CYLINDER	1
116	GRBN160	CYLINDER RING	1
117	GRBN295	BUMPER	1
118	GRBN164	DRIVER BLADE GUIDE	1
201	GRBN322	O - RING	1
202	GRBN323	TRIGGER VALVE HEAD	1
203	GRBN174	SPRING	1
204	GRBN324	PLUNGER	1
205	GRBN307	O - RING	1
205A	GRBN325	O - RING	1
206	GRBN326	O - RING	1
207	GRBN327	PLUNGER CAP	1
208	GRBN181	TRIGGER PIVOT PIN	1
209	GRBN305	HEX.SOC.HD.SCREW	1
210	GRBN328	ROLL PIN	1

REF #	PART #	DESCRIPTION	QTY
211	GRBN329	ROLL PIN	1
212	GRBN231	ROLL PIN	2
213	GRBN182	URETHANE RETAINER	1
214	GRBN298	SAFETY	1
215	GRBN299	TRIGGER	1
216	GRBN186	ROLL PIN	1
217	GRBN180	SAFETY GUIDE	1
218	GRBN330	SAFETY SPRING	1
301	GRBN293	GUN BODY UNIT	1
302	GRBN300	O - RING	1
303	GRBN301	END CAP	1
304	GRBN331	AIR PLUG CAP	1
305	GRBN28	AIR PLUG	1
401	GRBN309	BOLT ASSY	2
402	GRBN194	HEX.SOC.HD.BOLT	2
403	GRBN195	DRIVER GUIDE COVER	1
404	GRBN310	DRIVER GUIDE	1
405	GRBN197	MAGAZINE B	1
406	GRBN332	SAFETY	1
407	GRBN199	BRACKET	1
408	GRBN285	HEX.SOC.HD.BOLT	1
409	GRBN201	FLAT WASHER	1
410	GRBN202	HEX.SOC.HD.BOLT	1
411	GRBN203	PUSHER	1
412	GRBN204	MAGAZINE A	1
413	GRBN205	PROTECTING HOOD COVER	1
414	GRBN206	SPRING	1
415	GRBN207	LATCH	1
416	GRBN208	LATCH PIN	1

GRC58A

PARTS LIST

417	GRBN209	E - RING	1
418	GRBN210	PULL SPRING	1
419	GRBN211	RELIEF PLATE	1
420	GRBN333	SAFETY COVER	1
421	GRBN222	ANCHOR BLOCK	1
422	GRBN218	HALF ROUND HD.HEX.BOLT	2
423	GRBN334	HALF ROUND HD.HEX.BOLT	2
501	GRBN294	TOWER	1
502	GRBN335	FRONT PLATE A	1
503	GRBN336	SPRING	1
504	GRBN337	PUSHING	1
505	GRBN227	FLIPPER ARM	1
507	GRBN338	HEX.SOC.HD.BOLT	2
508	GRBN229	BELT HOOK	1
509	GRBN230	HEX.SOC.HD.BOLT	1
510	GRBN232	SPRING	1
511	GRBN9	HEX.SOC.HE.SCREW	2
512	GRBN10	TOWER DOOR	1
513	GRBN12	PLUG	1
514	GRBN11	FOLLOWER	1
515	GRBN302	HEX.SOC.HD.BOLT	1
516	GRBN14	ROLL PIN	1
517	GRBN13	NEG.DRUM	1
518	GRBN16	SPRING	1
519	GRBN287	HEX.SOC.HD.BOLT	4
520	GRBN311	COUNTER SUNK SCREW	2

521	GRBN236	BALL SPRING ASSY	1
522	GRBN339	FRONT PLATE B	1
523	GRBN228	HEX.SOC.HD.BOLT	1
601	GRBN340	SEAL	1
602	GRBN341	SPRING SEAL	1
603	GRBN342	COMPERSSION SPRING	1
604	GRBN343	PISTON	1
605	GRBN344	BUMPER	1
606	GRBN345	PISTON SHAFT	1
607	GRBN346	COLLAR	1
608	GRBN347	SEAL	1
609	GRBN348	PUSHER CONTACT	1
610	GRBN47	LOCK NUT	1
611	GRBN349	DEFLECTOR	1
612	GRBN350	C - RING	1
613	GRBN351	O - RING	2
614	GRBN352	EXHAUST VALVE B	1
615	GRBN353	O - RING	1
616	GRBN354	EXHAUST VALVE C	1
617	GRBN355	EXHAUST VALVE A	1
618	GRBN356	BRACKET	1

SPECIAL KITS

	GRDAK1300	DRIVER ASSEMBLY KIT	
	GRRBK1300	REBUILD KIT	
	MANC58A	OPERATORS MANUAL	
	CASEC58A	TOOL CASE	